
APPENDIX K. EXTERNAL N₂O REGULATOR VERIFICATION










Connect one end of a blue N_2O hose to the regulator output connector.



Connect the other end of the blue N_2O hose to the N_2O fitting from the Narkomed Kit Part # 4114807 (fitting with male connection).




Connect the High Pressure Test Gauge to the N₂O fitting.



Connect the hose of the High Pressure Test Gauge to male oxygen fitting from the Narkomed Kit Part #4114807.



Connect one end of the green oxygen hose to the fitting.




Setup the VT Plus to read N_2O . Power up and let it zero after 5 minutes. Press the pressure test mode button.


Press the setup button. Highlight settings and press enter.



Highlight gas settings and press enter.




Set the gas to read N2O.




Press back until in the pressure test mode again.



Connect the other end of the oxygen hose to the positive pressure connection of the VT Plus.







Disconnect all fittings, hoses, and components of this test and return to proper location.